


DCSB

Floor Scale



- **Rugged Construction**– Up to 6 mm / 0.25" thick top plate with heavy duty welded channel support
- **Legal for Trade**– All sizes are NTEP certified at 5,000 divisions
- **Low Profile**– 91 cm / 3.1 inches high; 44 mm / 1.75" adjustable leveling feet
- **Finish**– Powder coat paint
- **Versatile**– Pit mounted or free standing
- **Load Cells**– Four alloy tool steel potted
- **Mild Steel**

VALUE IN
WEIGHING

DCSB Floor Scale

Floor Scale Specifications

J-Box Access: Top access for easy installation and service

Leveling Feet: Four top access holes for a quick installation

Threaded Eye Bolts: Two threaded top access eye-bolt holes for easy mobility and pit service

Corner Protection: Closed corners to prevent damage to leveling feet while installing the scale

Floor Scale Material:

Construction: Mild steel

0.25 inch deck with safety tread,
10K (4' x 6'; 4' x 5'; 5' x 5')

0.19 inch deck with safety tread,
2 - 10K (3' x 3'; 4' x 4')

Finish: Powder coat paint

Rated: IP65

J-Box Construction: Stainless steel

Loadcell Material: Alloy tool steel potted

Loadcell Rated Output: 3mv/V

Loadcell Output Resistance: 350 ohm

Overload Protection: 150% of rated capacity

End Loading: 100% of rated capacity

Operating Temperature: -10° C to 40° C
14° F to 104° F

Accuracy: NTEP at 5000 divisions, Class III

Certifications: NTEP COC #02-070

Capacities & Resolution

Capacity	Model	Dimension-in.	Dimension-cm
5,000 x 1 lb (2500 x .5 kg)	DCSB4848-05 DCSB6060-05	48 x 48 x 3.1 60 x 60 x 3.1	122 x 122 x 7.9 152 x 152 x 7.9
10,000 x 2 lb (5000 x 1 kg)	DCSB4848-10 DCSB6060-10	48 x 48 x 3.1 60 x 60 x 3.1	122 x 122 x 7.9 152 x 152 x 7.9

All capacities and resolutions shown above are based on 5000d

Rugged Construction



Wide channel design for superior durability

Options

Ramps: Up to four ramps can be used with the DCSB family

Indicators: The DCSB can be used with a variety of electronic indicators

Pit Frames: Mild steel frames

Indicator Stand: 1219 mm / 48" high, mild steel, powder coat painted, for the Brecknell indicator. Includes stand, mounting hardware and floor mount baseplate.



a division of Avery Weigh-Tronix, LLC

Brecknell USA

1000 Armstrong Dr., Fairmont, MN 56031
Toll free: 800-637-0529, Tel: 507-238-8702
Fax: 507-238-8271
e-mail: sales@brecknell scales.com
www.brecknell scales.com



Brecknell UK

Foundry Lane, Smethwick
West Midlands B66 2LP UK
Tel: +44 (0) 845 246 6717
Fax: +44 (0) 845 246 6718
Email: sales@brecknell scales.co.uk
www.brecknell scales.co.uk

