



**MODEL PS-11**  
**DIGITAL PORTION SCALE**  
**OWNER'S MANUAL**

8528-M310-O1 Rev A  
04/04

CARDINAL SCALE MFG. CO.  
PO BOX 151 • WEBB CITY, MO 64870  
PH (417) 673-4631 • FAX (417) 673-5001  
Web Site - <http://www.detectoscale.com>



# INTRODUCTION

Thank you for purchasing our Detecto Model PS-11 Digital Portion Scale. The PS-11 is equipped with a rechargeable battery pack that (after 8 hours of charging) is able to provide up to 24 hours of continuous use. With this feature, it is ideal for use as a portable scale.

This manual will guide you through installation, and operation of your scale. Please read it thoroughly before attempting to operate this scale and keep it handy for future reference.

## FCC COMPLIANCE STATEMENT

**WARNING!** This equipment generates, uses and can radiate radio frequency and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area may cause interference in which case the user will be responsible to take whatever measures necessary to correct the interference.

You may find the booklet "How to Identify and Resolve Radio TV Interference Problems" prepared by the Federal Communications Commission helpful. It is available from the U.S. Government Printing Office, Washington, D.C. 20402. Stock No. 001-000-00315-4.

All rights reserved. Reproduction or use, without expressed written permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this manual, the Seller assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from use of the information contained herein. All instructions and diagrams have been checked for accuracy and ease of application; however, success and safety in working with tools depend to a great extent upon the individual accuracy, skill and caution. For this reason the Seller is not able to guarantee the result of any procedure contained herein. Nor can they assume responsibility for any damage to property or injury to persons occasioned from the procedures. Persons engaging the procedures do so entirely at their own risk.

<b>Serial Number</b> _____ <b>Date of Purchase</b> _____ <b>Purchased Form</b> _____ _____ _____ <p style="text-align: center;">RETAIN THIS INFORMATION FOR FUTURE USE</p>
---

# TABLE OF CONTENTS

Installation .....	1
Unpacking .....	1
Power Supply .....	1
Batteries .....	1
Low Battery .....	1
Display Annunciators .....	2
Key Functions .....	2
Operation .....	3
Configuration .....	4
Gravity Compensation .....	6
Display Messages .....	7
Care and Maintenance .....	7

## SPECIFICATIONS

Weight Display ...	LCD, 5 Digit, with fraction 0.8" x 0.3" Characters
Dimensions:	7.48" W x 9.84" D x 2.17" H (190mm x 250mm x 55mm)
Platform Size	6.89" W x 6.5" D (175mm x 165mm)
Zero	Established on power up routine and maintained by auto-zero circuitry.
Power	Built-in rechargeable battery pack (7.2VDC/1200mA) or 115 VAC 50/60Hz or 230 VAC 50/60 Hz powering a 15 VDC 300 mA wall plug-in UL/CSA listed power supply
Tare	100% of full scale capacity
Temperature	40 to 105°F (5°to 40°C)
Humidity	25% ~95% RH
	11lb x 0.1oz, 176 oz x 0.1oz, 176 oz x 1/4 oz, 5000g x 2g 11 lb x 0.005 lb
Keys	ON/OFF, ZERO, UNITS
Features	Low battery indicator, Power saving selectable timing auto shut-off

### PRECAUTIONS

Before using this instrument, read this manual and pay special attention to all "WARNING" symbols:



IMPORTANT



ELECTRICAL  
WARNING



# INSTALLATION

## UNPACKING

Before beginning installation of your scale, make certain the instrument has been received in good condition. When removing the scale from its packing, inspect it for signs of damage, such as exterior dents and scratches. Keep the carton and packing material for return shipment if it should become necessary. It is the responsibility of the purchaser to file all claims for any damages or loss incurred during transit.

1. Remove the scale from the shipping carton and inspect it for any signs of damage.
2. Plug-in the 15VDC adapter to use the scale and to begin charging the battery pack. Refer to the POWER SUPPLY or BATTERY PACK sections of this manual for more instruction.
3. Place the scale on a flat level surface, such as a table or bench.
4. The scale is now ready for use.

## POWER SUPPLY

To apply power to the scale using the supplied 15VDC, 300 mA power supply, insert the plug from the power supply cable into the power jack on the back of the scale and then plug power supply into the proper electrical outlet. The scale is now ready for operation.



## BATTERY PACK

The scale uses a 7.2VDC, 1200 mA built-in rechargeable battery pack. The PS-11 can operate for up to 24 hours of continuous use with a fully charged battery pack.

## BATTERY CHARGING

To recharge the battery pack, the power supply must be connected to a AC power outlet and plugged into the scale. It will take approximately 8 hours to fully recharge the battery pack in the scale. While the batteries are charging the PS-11 can still be operated. Note that charging the battery pack for more than 8 hours *will not* damage it.

If the power supply is disconnected before the 8 hours, the scale will continue to charge the battery pack when the power supply is plugged back in.

## LOW BATTERY

When the battery pack is near the point it needs to be recharged, a low battery indicator on the display will turn on. If the battery voltage drops too low for accurate weighing, the scale will automatically shut off and you will be unable to turn it back on. When the low battery indicator is displayed, the operator should plug the power supply into the scale and then into the proper electrical wall outlet. The scale will begin charging the battery pack.

# DISPLAY ANNUNCIATORS



The annunciators are turned on to indicate that the scale display is in the mode corresponding to the annunciator label or that the status indicated by the label is active.

## **O**

The **O** annunciator is turned on when the weight display is stable.

## **lb**

The **lb** annunciator is turned on to indicate that the displayed weight is in pounds.

## **oz**

The **oz** annunciator is turned on to indicate that the displayed weight is in ounces.

## **lb oz**

Both the **lb** and **oz** annunciators are turned on to indicate that the displayed weight is in pounds and ounces.

## **oz 1/4**

The **oz 1/4** annunciator is turned on to indicate that the displayed weight is in 1/4 ounce.

## **g**

The **g** annunciator is turned on to indicate that the displayed weight is in grams.



The low battery annunciator is used with the battery operation. It will turn ON to indicate that the batteries will soon need to be replaced.

# KEY FUNCTIONS

## **UNITS**

1. Press to change the weighing units to the alternate units of measurement (if selected during configuration of the scale).
2. Press to select menu in the Configuration mode.

## **ZERO**

1. Press to reset the display to zero up to 100% of the scale capacity.
2. Press and hold for 3 seconds to enter Configuration mode.
3. Press to confirm the setting for each menu.

## **ON/OFF**

1. Press and release to turn on scale.
2. Press and release to turn the scale off.
3. Press to confirm setting in Gravity Compensation mode.

# OPERATION

## TURN THE SCALE ON

Press the **ON/OFF** key to turn the scale on.

The scale will display



then change to the selected weighing units.

## SELECT THE WEIGHING UNIT

Press the **UNITS** key to alternate between the selected weighing units. **NOTE!** Multiple weighing units must be enabled during configuration for this function to be operational.

## WEIGH

Place the item to be weighed on the scale tray. Wait a moment for the scale display to stabilize, then read the weight.

## TO RE-ZERO THE WEIGHT DISPLAY

To re-ZERO (tare) the weight display, press the **ZERO** key and continue. The scale will re-ZERO (tare) until the full capacity is reached.



**The membrane keyboard is not to be operated with pointed objects (pencils, pens, fingernails, etc). Damage to keyboard resulting from this practice will *NOT* be covered under warranty.**

# CONFIGURATION

The Scale has been pre-configured at the factory and should not require configuration for use in most applications. In the event that the factory settings do not meet the requirements of your application, the following describes the steps to configure the scale.

## TO BEGIN CONFIGURATION:

1. Press the **ON/OFF** key to turn on the scale.
2. Press and hold the **ZERO** key for 3 seconds. When the display shows 5.00, release the **ZERO** key to enter the Configuration mode. The display will change to show Unit.

## WEIGHING UNITS

To select “lb/OZ” (pounds/ounce) weighing units:

1. With the display showing Unit, press the **ZERO** key. The display will change to show both “lb” and “OZ”.
2. Press **ZERO** key to display lb/OZ status.
3. Press the **UNIT** key to toggle between:  
Enable (display will change to On) or  
Disable (display will change to OFF).
4. Press the **ZERO** key and then the **UNIT** key 5 times. The display will change to Unit.
5. Proceed to AUTOMATIC SHUTOFF.

To select “OZ” (ounce only) weighing units

1. With the display showing Unit, press the **ZERO** key and then the **UNIT** key. The display will change to show “OZ”.
2. Press the **ZERO** key to display OZ status.
3. Press the **UNIT** key to toggle between:  
Enable (display will change to On) or  
Disable (display will change to OFF).
4. Press the **ZERO** key and then the **UNIT** key 4 times. The display will change to Unit.
5. Proceed to AUTOMATIC SHUTOFF.

To select “1/4 OZ” (fractional ounce) weighing units:

1. With the display showing Unit, press the **ZERO** key and then the **UNIT** key 2 times. The display will change to show “OZ” and “1/4”.
2. Press **ZERO** key to display 1/4 OZ status.
3. Press the **UNIT** key to toggle between:  
Enable (display will change to On) or  
Disable (display will change to OFF).
4. Press the **ZERO** key and then the **UNIT** key 3 times. The display will change to Unit.
5. Proceed to AUTOMATIC SHUTOFF.

## CONFIGURATION, Cont.

To select “g” (gram) weighing units:

1. With the display showing **Unit**, press the **ZERO** key and then **UNIT** key 3 times. The display will change to show “g”.
2. Press **ZERO** key to display g (gram) status.
3. Press the **UNIT** key to toggle between:  
Enable (display will change to **On**) or  
Disable (display will change to **OFF**).
4. Press the **ZERO** key and then the **UNIT** key 2 times. The display will change to **Unit**.
5. Proceed to AUTOMATIC SHUTOFF.

To select “lb” (pounds only) weighing units:

6. With the display showing **Unit**, press the **ZERO** key and then **UNIT** key 4 times. The display will change to show “lb”.
7. Press **ZERO** key to display lb status.
8. Press the **UNIT** key to toggle between:  
Enable (display will change to **On**) or  
Disable (display will change to **OFF**).
9. Press the **ZERO** key and then the **UNIT** key. The display will change to **Unit**.
10. Proceed to AUTOMATIC SHUTOFF.

### AUTOMATIC SHUTOFF

1. With the display showing **Unit**, press the **UNIT** key. The display will change to show **ROFF**.
2. Press the **ZERO** key to begin selection of the automatic shut-off time (in seconds). The display will change to show **120**.
3. Press the **UNIT** key to toggle through the selections, **120**, **180**, **240**, **300**, or **OFF**.
4. When the desired time is displayed, press the **ZERO** key. The display will change to show **ROFF**.
5. Proceed to GRAVITY COMPENSATION.

### GRAVITY COMPENSATION

1. With the display showing **ROFF**, press the **UNIT** key. The display will change to show **GRAV**.
2. With the display showing **GRAV**:  
To Enable the Gravity Compensation mode, press the **UNIT** key. The display will change to **On**.  
To Disable the Gravity Compensation mode, press the **UNIT** key. The display will change to **OFF**.
3. Press the **ZERO** key again. The display will change to show **GRAV**.
4. Press the **UNIT** key. The display will change to show **End**.
5. Press the **ZERO** key to save the settings and reset the scale.
6. Setup is complete.

## GRAVITY COMPENSATION

The Gravity Compensation for your scale has been pre-configured at the factory and should not require changing in most locations. In the event that the factory settings do not meet the requirements of your location, contact the factory for the value for your location.


With  $\boxed{GRAV}$  enable from the function setting of the Configuration mode, the scale will use the factory set value of 9.797 for the Gravity Compensation.

If the  $\boxed{GRAV}$  is disabled, the scale will use the value obtained from the factory and entered by the operator for the Gravity Compensation.

### To change the Gravity Compensation value:

1. Press the **ON/OFF** key to turn on the scale.
2. Press and hold the **UNITS** key 3 seconds to enter Gravity Compensation mode, the display will show 9.797 (or the current value).
3. Enter the desired gravity value (press the **ZERO** key to choose number from 0~9, and press **UNITS** key to move to right digit).
4. Press **ON/OFF** key (to confirm the entered gravity) and return the scale to the normal operating mode.

## DISPLAY MESSAGES

DISPLAY	MEANING
	Low battery indication
<i>ErrE</i>	E <sup>2</sup> prom Error
<i>ErrL</i>	Zero count under 128
- - - - -	Over capacity (upper dashes)
- - - - -	Under capacity (lower dashes)
<i>ErrH</i>	Zero count over 65,000
<i>SPnH</i>	Calibration span too high
00000	Power-on zero count under calibration zero (-10%)
00000	Power-on zero count over calibration zero (+10%)

## CARE AND MAINTENANCE

The heart of the PS-7 Digital Portion Scale is a precision load cell located in the center of the scale base. It will provide accurate operation indefinitely if protected against overload of scale capacity, dropping items on scale, or other extreme shock.

- **DO NOT** submerge the scale in water, pour or spray water directly on it.
- **DO NOT** use acetone, thinner or other volatile solvents for cleaning.
- **DO NOT** expose scale to direct sunlight or temperature extremes.
- **DO NOT** place scale in front of heating/cooling vents.
- **DO** clean the scale with a damp soft cloth and mild non-abrasive detergent.
- **DO** remove power before cleaning with a damp cloth.
- **DO** provide clean AC power and adequate protection against lightning damage.
- **DO** keep the surroundings clear to provide clean and adequate air circulation.

